

## User information the Rising Balance candleholder

### Distance

- Keep other objects at a safe distance from the candleholder keeping in mind its range of movement.

### Supervision

- Never burn the candle without supervision.

### Maintenance

- Keep the brass clean and dry. Make sure the tea light holder is free from candle wax so that it can rise easily. Put the round wood under the light to keep your table clean (1).
- Do not bend the candleholder. Gently clean the long brass part so it can continue balancing properly (2).

