

ICON **QALARM** INSTRUCTION MANUAL **ENGLISH**
















CONTENTS


FEATURES	
INSERTING BATTERIES	4
BATTERY LEVEL	4
POWER ON	4
CONTROL KNOBS	ĺ
DROPBACK DETECTION	Ĺ
LOCAL MUTE	Ę
LOCAL UNMUTE	í
PAIRING	í
FACTORY DEFAULT	Ĺ
SEESAW ELIMINATION	6
ALERTS	6
LED ILLUMINATION COLOURS	6
NIGHTLIGHT LED COLOUR	-
NIGHTLIGHT LED BRIGHTNESS	- -
LOCKING NUT	- -
PORT RUBBERS	-
IQ PORT	
SMART PORT	
AD II IOTA (ENIT. OF DITE AL ADA)	
ADJUSTMENT OF BITE ALARM CONTROLS FROM HUBB	8
ROLLER SENSITIVITY SETTING LEVELS	(
LED ILLUMINATION COLOURS	(
BITE LED BRIGHTNESS	(
ALERT TIMEOUT	5
ALERT VOLUME	(
ALERT TONE	(
NIGHTLIGHT SETTINGS	(
BATTERY LEVEL INDICATION	(
BANGE TEST	(
MUTE	,
	`

FEATURES

- High Sensitivity Roller Wheel
- Roller Wheel Detection 8 Sensitivity Levels, expandable to 16 via HUBB link
- Dropback Differentiation and See Saw Elimination
- High Visibility Dual Bite LED's 4 Changeable Colours -Green, Blue, Yellow or Red
- LED'S Indicates Forward and Backward Flashes on dropback
- LED'S Times adjustable and Stealth mode (LED'S Off)
- Piezo Speaker
- Auto Night Light 4 Changeable Colours and Auto Level Adjustment & Manual Level Adjustment via HUBB
- Indicator Port Smart LED Drive, colour change on bite detection
- IQ Port Links other ICON Accessories
- HUBB Link Receives and Transmits Commands to HUBB
- Pairing Button
- Menu Button
- Extreme Transmit/Receive Range
- Fully Sealed Waterproof Electronics
- Battery Level Indication
- Indication type Event sent to HUBB

- Mute 60/30 Seconds Selectable
- On/Off Sensitivity Dial
- Hard Case
- Non-Slip Rubber Grip & Rod Protectors
- Stainless Steel Stud & Locking Nut
- Battery Life 1000 hrs on Standby
- Beta Light Slots x 2 Size 6mm x 2mm
- Rubber Socket Covers
- Range 2km Line of Sight
- Power Down Alert To HUBB Anti Theft
- Volume Settings Adjustable from Alarm & Main HUBB
- Tone Settings Adjustable from Alarm & Main HUBB
- Dedicated WOLF Vibration Tone
- Tone difference Run Forward & Dropback
- Latching Run Time 30 Seconds Adjustable via main HUBB
- Low power mode is available when not paired to Hubb only.
 After Hubb pairing LP mode can be re-enabled by a hard reset of the Bite Alarm
- UV Stable Material & Robust Symbol Markings
- 1mt Drop Test
- Warranty 2 Years Register you ICON at www.wolfint.com.

INSERTING BATTERIES



To insert batteries use a Philips screwdriver and open 2 screws on battery compartment. When inserting new batteries always replace all of them and turn off Alarm before replacing. After use of Alarm in damp conditions leave to dry out somewhere warm before packing away and if not going to be used for a while it is recommended to remove batteries in case of leakage. Be careful when attaching Alarm to banksticks, buzz bars etc. and avoid over-tightening. See website for full care advice and instructions.

BATTERY LEVEL

The Battery Level of the Bite Alarm can be displayed by pressing ...



POWER ON



To power up the Bite Alarm, turn the sensitivity knob away from the Off position. On start-up the battery level is indicated.

To turn off the Bite Alarm, switch the sensitivity knob to Off. Await the shutdown tone to confirm.

NOTE: Hard case will not shut off Alarm.

RUBBER SOCKET HOLDERS



When IQ Port or Smart LED Port are not being used the rubber socket holders should be pressed into ports. When not needed they should be pressed into the socket holders on reverse of Alarm.





CONTROL KNOBS

The Bite Alarm control knobs can be used to adjust various settings.



The sensitivity knob adjusts the amount of line travel before an alert is triggered. There is also an Off position to turn the Bite Alarm off. 8 Sensitivity Levels, expandable to 16 via HUBB link. 2mm, 6mm, 11mm, 17mm, 25mm, 34mm, 61mm, 101mm. *Additional Hubb Settings 4mm, 8mm, 16mm, 20mm, 30mm, 40mm, 80mm & 100mm.



The volume knob adjusts the volume of the alerts on the Bite Alarm.





The tone knob adjusts the pitch of the alerts on the Bite Alarm.

DROPBACK DETECTION

During a dropback detection, a two tone signal is triggered and the LED's should flash.

LOCAL MUTE

The Bite Alarm can be temporarily muted by pressing the ** button. Multiple presses of the ** button achieve different actions.

BUTTON PRESS	DESCRIPTION
1 X ■ ×	The Bite Alarm is muted for 30 seconds.
2 X ■ ×	The Bite Alarm is muted for 60 seconds.
3 X ■ ×	The Bite Alarm is not muted.

LOCAL UN-MUTE

The Bite Alarm can be un-muted after it has been muted. A single press of the **4**× button will un-mute the Bite Alarm.

PAIRING

When the receiver device is ready for pairing with HUBB (see receiver device instructions), press and hold the **
button until indicator LED turns Blue then release Button, this will initiate pairing.

FACTORY DEFAULT

To reset the Bite Alarm to factory settings, and remove all user data, hold the *\sim \text{button while powering on the Bite Alarm. After the LED's illuminate, release the *\sim \text{button. A tone will play to confirm the reset.}

SEE-SAW ELIMINATION

The Bite Alarm includes See-Saw elimination. For a given distance of line travel 4mm extra in the opposite distance is needed before an alert is triggered.

ALERTS

ALERT TYPE	LED INDICATION	SOUND
Forward	Solid Alert Colour	Single Tone at user selected pitch.
Dropback	Flashing Alert Colour	Tone at alternating pitch.
IQ Empty IQ Trigger	Solid Alert Colour	Piercing security tone.
Battery Critical	Flashing Red	No tone played.

MENU BUTTON

By pressing and holding the & menu button the configuration menu can be entered, indicated by a special tone.

LED ILLUMINATION COLOURS









While in the configuration menu the volume knob adjusts the colour of the LED colours.
4 colours are available:

Blue Yellow Green Red Stealth Mode (Off)

WARNING ABOUT BRIGHTNESS OF LED'S

NIGHTLIGHT LED COLOUR



While in the configuration menu the Tone knob adjusts the colour of the Nightlight LED. There are 4 selectable colours: Blue - Yellow - Green - Bed - Off.

LED ILLUMINATION BRIGHTNESS

While in the configuration menu the pressing the Mute button toggles the LED and Nightlight brightness high/low. Modes Selectable:

Bite LED 100% Nightlight 100%
Bite LED 10% Nightlight 100%
Bite LED 100% Nightlight 10%
Bite LED 10% Nightlight 10%

LOCKING NUT



Ratur molupta temperi aut volume imporestis eatam harchit laturib eaquibustem rempor atia ipsus soloreria non entisqui con rerum sin rerovit ant.

IQ PORT

Ratur molupta temperi aut volume imporestis eatam harchit laturib eaquibustem rempor atia ipsus soloreria non entisqui con rerum sin rerovit ant.

Acescid exped quamenis enem corp

SMART LED PORT

Ratur molupta temperi aut volume imporestis eatam harchit laturib eaquibustem rempor atia ipsus soloreria non entisqui con rerum sin rerovit ant.

Acescid exped quamenis enem corp

ADJUSTMENT OF BITE ALARM CONTROLS FROM HUBB

DEVICE MENU

When the HUBB has been paired with Alarms press the corresponding Alarm channel to change any settings. Press and hold channel button until 'Device Menu' is shown on screen.

On activation of the bite Alarm the tone should be replicated



on the HUBB and the HUBB
LED's should replicate the alert
colour shown on the bite Alarm.
Depending on the HUBB's settings,
the HUBB will also vibrate on alert.
When 'Device Menu' is shown, use
OK button to enter sub menu.

Go to 'Sensitivity' to adjust the connected bite Alarm line sensitivity. When confirming this option a message will be sent to the bite Alarm, if successful you will be notified on screen.

ROLLER SENSITIVITY SETTING LEVELS



8 Sensitivity Levels, expandable to 16 via HUBB Link

2mm, 6mm, 12mm, 18mm, 25mm, 35mm, 60mm or 100mm.
Additional Sensitivity Levels
4mm, 8mm, 16mm, 20mm,

30mm, 40mm, 80mm or 300mm.

LED ILLUMINATION COLOURS



Go to 'Alert Colour' to change the colour used to display alerts on the bite Alarm and HUBB.

4 Colours: Blue - Yellow - Green - Red - Stealth Mode (Off)

BITE LED BRIGHTNESS



Go to 'LED Brightness' to change the brightness of the LED's displayed on the bite Alarm.

ADVANCED MENU



Use the back button to leave 'Device Menu' and go 'Advanced Menu' and use OK button to enter this menu.

ALERT TIMEOUT



Go to 'Alert Timeout' to adjust the time that the LED remains turned on after an alert on the bite Alarm.

60 seconds / 30 seconds / 20 seconds / 10 seconds / 5 seconds

ALERT VOLUME



In 'Advanced Menu' go 'Alert Volume' to adjust the volume of the bite Alarm alert.



ALERT TONE



In 'Advanced Menu' go 'Alert Tone' to adjust the pitch on the Alarm and the HUBB.

NIGHTLIGHT SETTINGS



In 'Advanced Menu' go 'Nightlight Config'. Find the first option titled 'Nightlight Brightness' and adjust to manual setting.

Go to second option 'Nightlight Brightness' and adjust as desired.

Go to option 'Nightlight Colour' and adjust as desired.

Colours available:

Red - Green - Blue - Yellow and Off.

Go to 'Nightlight to Port'. When this option is turned on the Nightlight colour should be copied to any connected Wolf hanger or swinger.

DEVICE STATUS

Use the back button to leave 'Advanced Menu' and navigate to the option titled 'Device Status' and enter sub menu using OK button.

BATTERY LEVEL INDICATION (PING PONG)



Navigate to the option 'Battery Level'. This provides a detailed measurement of the Alarms battery level.

RANGE TEST (PING PONG)



Navigate to the option 'Range Test' and use the OK button to begin the test. When a connection is established the HUBB will report the signal strength of the connected Alarm and also indicates that the LED is working.

ANTI-THEFT

When turning off the connected Alarm, a tone should be played on the Alarm and HUBB for theft prevention.

MUTE

Pressing the Mute button once should mute all connected Alarms. On activation neither the HUBB or Alarm should play a tone. A double press of the Mute button should undo the mute on the HUBB and Alarms.

WOLF INTERNATIONAL

Unit 3, 284 Warley Hill, Great Warley, Brentwood, Essex CM13 3AB

E: sales@wolfint.com T: +44 203 885 1230

E: support@wolfint.com

www.wolfint.com

Patents Pending:

GB 1721169.9

GB 1721166.5

GB 1721158.2

EP 18213109.4

EP 18213012.0

EP 18213022.9





Troubleshooting etc.

Xim quibea dellauta que maio. Eceptatates et as sapidic imusaped etur se endios abo. Cepratus esequi sundiae omnihil illautenis im landige ndigeni molupitius aut fugia conseque con rescit antorer umquiassi sum ellaces eum num solest, quatur? Quis e dit est, qui deruntius, simi, cus quatest ionsed quid qui volo molupti dolorenis nis autam fugia explisi tiumquiae ium nisquia

Warranty

If you need information to the warranty please visit www.wolfint.com/product-warranty/

Please ensure to register your new Wolf product at www.wolfint.com/product-registration/

Customer Support

If you need support you can contact us by:

Telephone: +44 203 885 1230 Email: support@wolfint.com

More information can be found at www.wolfint.com/customer-support/

For language translations of all instructions and functions and care of your Wolf international ICON Alarm Or Hubb visit www.wolfint.com/product-manuals/













